













Montážní návod

Assembly instruction

BTP80, BTP90



<p>A1</p>  <p>M4X30</p> <p>x3</p>	<p>A2</p>  <p>x3</p>	<p>A3</p>  <p>2. 8MM</p> <p>x1</p>	<p>A4</p>  <p>M4X10</p> <p>x6</p>
<p>A5</p>  <p>x6</p>	<p>A6</p>  <p>x1</p>	<p>A7</p>  <p>x1</p>	<p>A8</p>  <p>x1</p>

