

INSTALLATION INSTRUCTION

TWO HANDLES BATH-SHOWER MIXER


※ACCESSORIES CHECKING

LIST OF THE STANDARD ACCESSORIES:


Please double-check the accessory list hereafter and contact our company or our distributor for any unconformity.

Remarks:

1. Without affecting their performing, accessories may be changed without further notice;
2. Drawings for reference only. Product size & shape refer to actual faucet.



Code	The Accessory List	Quantity
1	Main body	1
2	O-ring	2
3	Flange	2
4	Eccentric nut	2






※Installation Instructions

- ☆ Do not disassemble the main body, as it has been installed & commissioned correctly & precisely before leaving the factory;
- ☆ To avoid the faucet from jamming, do flush the water pipe before installation;
- ☆ After installation, make sure every joint is safely sealed & no leaking;
- ☆ Using condition: Working pressure at 0.05-1.0MPa (including cold & hot water pressure), with applicable water temperature: 4°C-90°C;
- ☆ Make sure to connect the hot/cold inlet pipe correctly if standing in front hot water pipe connecting to the left & cold water pipe connecting to the right.

※Installation Procedures

- ☆ Please install the connection hose into the wall according to the installation Procedures.




※Usage

☆How to operate the handle

- 1) Raise the handle lever up for opening water; push it down for close;
- 2) Turn the handle lever to the left to increase hot water flow for higher water temperature and lower water temperature by operating reversely.

☆The diverter instruction:

1. Pull the diverter up and then the showerhead come out
- Meanwhile the aerator turn off;
2. Contrarily, fixing the diverter down, the aerator come out and then showerhead turn off.



※Cleaning & Maintenance

☆ To keep the product clean & shining follow the as below:

1. Flush with clean water & dry with soft cloth only;
2. If any dirt, clean with soft liquid or transparent glass detergent;
3. Do not use any scrubbing detergent, polisher, same-cloth, paper tissue or scraper;
4. Do not use acid detergent, indissolvable grain-like detergent or soap;
5. Circumvent the aerator off and clean it when necessary.

